



DAILY/WEEKLY THERMOSTAT · BERNINI · CR 125

EN 60730-2-9 EN 60730-1

Install at a height at about 1,5 m above the floor, avoiding heat sources, windows and doors.

The device work by default in Daily operation.

Open the battery compartment of the programmable thermostat to insert / replace the batteries.

Automatic switch-on when batteries are inserted.

After batteries insertion we have 10 seconds to decide whether to set the chronothermostat Weekly by press and keep hold and + of (7 dAy appear), and Daily by press and keep hold and - of (1 dAy appear).

Factory settings: Daily operation, Heat mode on , Antifreeze mode at 5°C.

Comfort Temp. 22°C, Economy Temp. 10°C, Diff. 0.3°C, Correction Temp. 0,0°C.

When system is working or is animates.

The following indications are valid for both models, where otherwise is indicated.

SWITCH ON / OFF:

Press for 3 seconds.

Manual or Automatic operation:

In AUTOMATIC operation where the time boxes are shown on the screen the Comfort temperature is selected; otherwise is selected the Economy temperature. Press to set AUTOMATIC or MANUAL operation.

MENU: Navigate inside the Menu using the + and - keys of

1. TIME SETTINGS:

In Menu select and confirm **OK**, set the hour and confirm **OK**, set the minutes and confirm **OK**;
If weekly operation select the + and - keys of and confirm **OK**.

2. TEMPERATURE PROGRAM (only WEEKLY): **P**

In Menu select **P**, select the day to set and confirm **OK**,
Press the key of the desired hour to set the start in according to the COMFORT temperature.

3. SET THE TEMPERATURE THRESHOLD:

Press the + and - keys of to set the COMFORT temperature
Press the + and - keys of to set the ECONOMY temperature

4. REMOTE OPERATION: **r**

In Menu select **r**, select the number of the hours in which it must remain active and the temperature with the + and - keys of

5. HEATING:

In Menu , select and confirm **OK**.

6. COOLING:

In Menu , select and confirm **OK**.

7. PARAMETER SETTING:

7.1 ANTIFREEZE:

It's important to avoid too low temperature damage.

From select ; then set the value with the + and - keys of and confirm **OK**.
Below 2° C the antifreeze protection is lost and OFF appears.

7.2 THERMAL DIFFERENTIAL: **diFF**

Repeat step 7.1, press Menu for 3s, set the value and confirm **OK**.

7.3 MEASURED TEMPERATURE CORRECTION: **corr**

Repeat steps 7.1 and 7.2, press Menu for 3s and set the correction, confirm **OK**.

Reset:

Remove and reinsert the batteries.

Device must be installed by a qualified person.

For more and detailed information, see the installer manual at tecnoswitch.com

Tecno Switch reserves the right to make changes to its products in each moment and without further notice.

Tecno Switch declines all responsibility for damage to things or persons derived from an incorrect or improper use of its products.

